



## VESA Landscape/Portrait Installation Instructions



**IMPORTANT -  
DO NOT LOOSEN WING KNOB  
BEFORE INSTALLING!**

Install the Landscape/Portrait VESA Plate or the QR-L/P Receiver Plate to the spigot mount with the provided 1/4-20 Flat Head Countersunk screws before loosening the wing knob.

1/4-20 Flat Head Countersunk Screws are provided at different lengths for various installs of the L/P or QR-L/P Plate to either our MMS Spigot Monitor Mount or to our Whaley Rail Clamp.



**MMS09/MMS12/MMS11/MMS11-MC  
Spigot Monitor Mount**

Use provided 1/4-20 x 3/4 SS Flat Head Screws



**Whaley Rail Clamp**

*Whaley Rail Clamp Spacer (#13585) is required*

Use provided 1/4-20 x 1-3/4 Alloy Flat Head Screws



Once installed to spigot mount and with monitor attached, check landscape/portrait friction.\*

For friction adjustment on the landscape to portrait swing movement, use a 3mm Hex key to adjust via the set screw.

*\*When checking friction without monitor attached, the friction preset will seem difficult to adjust. Note this is due to the absence of the leverage that the monitor provides. Always best to check with monitor attached.*

For Upgrade Innovations monitor mounts. Always check load rating of monitor mount. All mounting and installation shall conform to FD manufacturer and VESA Flat Display Mounting Interface (FDMI) Standard